



1
E2
(ELECTRICAL) 1/8"=1'-0"

DEMOLITION LEGEND:
 ——— LIGHT LINES = EXISTING TO REMAIN
 ——— DARK SOLID LINES = EXISTING TO BE REMOVED

- GENERAL DEMOLITION NOTES:**
- CUTTING AND PATCHING OF THE WALLS, FLOORS, AND CEILING FOR INSTALLATION OF ELECTRICAL WORK IS THE RESPONSIBILITY OF THE CONTRACTOR.
 - DISCONNECT ALL ITEMS WHICH ARE TO BE REMOVED AND/OR RELOCATED.
 - ALL RACEWAYS AND CABLES SHALL BE CONCEALED UNLESS NOTED OTHERWISE.
 - PROVIDE NEW CONDUCTORS, RACEWAY, ETC., AS REQUIRED TO MAINTAIN OPERATION OF EXISTING OUTLETS, EQUIPMENT, ETC., WHICH REMAIN OR ARE RELOCATED, I.E. IF CIRCUIT FEEDING EXISTING DEVICE IS AFFECTED BY DEMOLITION OR NEW CONSTRUCTION, REROUTE AS REQUIRED TO KEEP EXISTING DEVICES OPERATIONAL.
 - NO EXISTING WIRING MAY BE REUSED IN THE NEW ELECTRICAL WORK UNLESS SPECIFICALLY NOTED.
 - ALL EXISTING CIRCUITS AND WIRE THAT ARE NOT IN USE AFTER DEMOLITION IS COMPLETED SHALL BE REMOVED.
 - EXISTING LIGHT FIXTURES WHICH ARE NOT REUSED SHALL BECOME THE PROPERTY OF THE CONTRACTOR. ALL REMOVED MATERIALS ARE TO BECOME THE PROPERTY OF THE CONTRACTOR AND ARE TO BE REMOVED AND DISPOSED OF PROPERLY. THIS INCLUDES DISPOSING OF BALLASTS AND LAMPS PER EPA REQUIREMENTS.
 - EXISTING CONDUITS IN THE FLOOR WHICH ARE NOT USED AND WHICH ARE ABANDONED SHALL BE TRIMMED TO BELOW FLOOR SURFACE, CAPPED AND THE FLOOR PATCHED. FINISH FLOOR TO MATCH EXISTING.
 - WORK SHALL BE PERFORMED WITH NO DISRUPTION OF THE OWNER'S BUSINESS. ALL ELECTRICAL POWER DISRUPTIONS SHALL BE SCHEDULED AND APPROVED BY THE OWNER.
 - ALL WORK IN STRICT ACCORD WITH NEC, STATE AND LOCAL BUILDING CODES.
 - ALL ELECTRICAL ITEMS SHOWN IN DARK ON DEMOLITION PLANS ARE TO BE REMOVED.
 - IN CERTAIN AREAS WALLS WILL BE FURRED OUT OR MODIFIED. IF DEVICES ARE SHOWN TO REMAIN THEY MAY REQUIRE BEING EXTENDED ETC. AS REQUIRED BY NEW OR MODIFIED WALL. SEE ARCHITECTURAL DRAWINGS AND MODIFY AS REQUIRED.
 - WHERE DEVICES ARE SHOWN REMOVED, BOX AND CONDUIT MAY REMAIN IF MASONRY WALL REMAINS. INSTALL BLANK COVERPLATE OVER BOX TO MATCH EXISTING COVERPLATES IN ROOM. REMOVE CONDUCTORS BACK TO CIRCUIT BREAKER IN PANEL, UNLESS THE CIRCUIT FEEDS OTHER LOADS WHICH MUST REMAIN ACTIVE.
 - WHERE TELEPHONE OUTLETS ARE SHOWN REMOVED, AND WALL REMAINS, LEAVE BOX, CONDUIT, AND CONDUCTORS IN PLACE FOR FUTURE USE. INSTALL BLANK PLATE OVER BOX.
 - EXISTING CONDUIT MAY BE UTILIZED WHERE POSSIBLE.

C:\jga\CAD\9504\MECH\9504E2 Tue Dec 17 17:26:08 1996 JGA ARCHITECTS BILLINGS, MT